



A question of shrinking assembly time

This is a product for anyone who wants to avoid complicated assembly and time-consuming shrinkage of filter cloths. For the frame-mounted filter, fitting is considerably faster and simpler thanks to the filter cloth being tailored to the right shape. After assembly, a perfect fit is obtained by letting the cloth shrink for about five to ten minutes in a hot environment preferably containing some steam. The wear protection and reinforcements are already sewn on where the filter adjoins the frame. This markedly reduces the risk of any tearing in the cloth during both installation and operation.



TEKNISKA PRECISIONSFILTER JR AB

Anton Tamms väg 3
SE-194 34 Upplands Väsby
Sweden

Phone: +46-8-59411240
Fax: +46-8-59070285

tpfilter@tp-filter.se
www.tp-filter.se

Bankgiro: 414-4135
Org.nr: 556189-9997

Quality-line

Precisionsfilter enligt ISO 9001/14001